

AG915S ®

NO	DESCRIPTION	NO.	DESCRIPTION
1	DUST COVER	40	SCREW
2	ALUMINIUM PLATE	41	STOP PIN
3	HEAD HOUSING	42	KEY
POVE	NAME PLATE	43	LOCALIED POLE
5	SCREW	44	BLOCK
6	CUTSHIFT	45	BRUSH HOLDER COVER
7	FRONT COVER PLASTIC KNOB	46	BRUSH
8	SCREW	47	BRUSH HOLDER
9	SPRING FLANGE	48	SWITCH
10	FRONT COVER	49	SWITCH COVER
11	BEARING	50	SINGLE SWITCH
12	UNDER WASHER	51	ALUNIUM HANDLE
13	HOLE CHEECKING	53	CLEAN KNOT CONNECTING
14	GEAR	54	RUBBER KNOT
15	AXLE CHECKING	55	CONNECTING KNOT
16	BEARING	56	CLEAN KNOT
17	MOTOROVVER • G	57	SCREW O
18	SCREW	58	ENCIRELE RING
19	STOP PIN SPRING	59	SCREW
20	STOP COVER	60	LOWER FLANGE
21	SCREW NUT	61	CUTTING BLADE
22	SMALL GEAR	62	ADJUSTING FLANGE
23	BALL	63	GIBBUSE FLANGE
24	BEARING	64	"T" SCREW NUT
25	BEARING COVER	65	UPPER FLANGE
26	SCREW	66	MANTLE COVER
27	ROTOR	67	SCREW
28	BEARING	68	NAME PLATE
29	BEARING BUSH	69	RUBBER RING
	BLOWING GRIDED A N	70	FOURSQUARE SCREW
31	NET COVER	71	FLANGE
32	REAR COVER	72	SIDE HANDLE
33	CORD PLUG	73	SCREW
34	CORD FLANGE	74	SPRING
35	SCREW	991	T-WRENCH
36	CORD FLANGE	992	SPANNER
37	NAME PLATE	993	HEX WRENCH
	HOUGINO		
38	HOUSING		

POWER • GAS • HAND • TOOLS